



SPARE PARTS LIST
REFRIGERATION

Index

Controls

Doors and Interior


Cabinet and Cooling Units

Power Board and Gas Assembly

Seals, Vents and Exhausts

Colour Index


Code Explanation



LO 001-EXPLODED

Controls Piezo ignition 486 & 525 (LO-001)



	Single spare part number	Assembly spare part number
1	Control knob	62302607 (Light grey) 62302630 (Mocha)
2	Control knob	62568207 (Light grey) 62568230 (Mocha)
3	Overlay Piezo 486	626620
3	Overlay Piezo 525 • Not for N98 or N115	626622
4	Control panel	62700207 (Light grey)
5	Piezo igniter grey	625689
6	Nut	623400
7	Selector switch 5p	
7	Selector switch 6p • As from July 1 st 2005. • Also for N98 and N115	626999 (includes Nut)
8	Bracket piezo/switch	
9	Terminal strip AC	
9A	Terminal strip DC	
10	Strain relief	
11	AC control cover	
12	Screw (3x)	
13	Bushing	
14	AC cover TGV	
15	Gas valve manual V2	62568807
16	Axle TGV	
17	Flame meter	623029
18	Bracket TGV	



LO 002-EXPLODED

Controls Electric ignition 486 & 525 (LO-002)

	Single spare part number	Assembly spare part number
1 Control knob	62302607 (Light grey) 62302630 (Mocha)	
2 Control knob	62568207 (Light grey) 62568230 (Mocha)	
3 Overlay Electric 486	626621	
3 Overlay Electric 525	626623	
4 Control panel	62700207 (Light grey)	
6 Nut		623400
7 Selector switch 5p		
7 Selector switch 6p		626999 (Includes Nut)
7 <ul style="list-style-type: none"> • As from July 1st 2005. • For N115 		
8 Bracket piezo/switch		
9 Terminal strip AC		
9A Terminal strip DC		
10 Strain relief		
11 AC control cover		
12 Screw (3x)		
13 Bushing		
14 AC cover TGV		
15 Gas valve manual V2	62568807	
16 Axle TGV		
17 Flame meter	623029	
18 Bracket TGV		




LED00-EXPLODED

Controls LED (LED00)

Single spare part number

Assembly spare part number

1	Control Panel LED	62700207
2	Overlay LED	627000
3	Display board LED V2	626997
4	Insulator	
5	Push on nut	
6	Bracket	




LED01-EXPLODED

Controls LED Fridge freezer (LED01)

Single spare part number

Assembly spare part number


1	Control Panel LED	62700307
2	Overlay LED Fridge freezer	625684
3	Display board LED V2	626997
4	Insulator	
5	Push on nut	
6	Bracket	



LE270_EXPLODED


Controls LCD flat (LE270)

	Single spare part number	Assembly spare part number
1	Overlay LCD EES (electric)	626975
	Overlay LCD SES (automatic)	631737
2	Screw	
3	Control Panel LCD flat	62697407
4	Screw	
5	Push buttons	
6	Display board LCD	626972
7	Mounting box (Not for all models)	



Controls LCD curved (LE230)


	Single spare part number	Assembly spare part number
1	Overlay LCD EES (electric)	626975
	Overlay LCD SES (automatic)	631737
2	Screw	
3	Control Panel LCD curved	62697307
4	Screw	
5	Push buttons	
6	Display board LCD	626972
7	Mounting box (Not for all models)	



LE422 EXPLODED

Controls LCD curved (LE442)

	Single spare part number	Assembly spare part number
1	Overlay LCD EES (electric)	626975
	Overlay LCD SES (automatic)	631737
2	Control Panel LCD curved	62697307
3	Push buttons	
4	Screw	
5	Display board LCD	626972




LO 003-EXPLODED

Door & Cabinet Interior N80 (LO 003)

	Single spare part number	Assembly spare part number
1	Screw (3x)	
2	Hinge plate	
3	Hinge pin bottom/washer	
4	Door flat low 486	625555R
5	Pocket cover	
6	Screw (2x)	
7	Hinge plate	
8	Hinge pin top/washer	
9	Screw (3x)	
10	Screw (2x)	62302407
10A	Screw (2x)	
10B	Strike Plate	
11	Latch	
11A	Storage strap	62467907/-90 (2x)
12	Hinge hole plug	
13	Doorbin	62304008
14	Doorbin	62402308
15	Bottle retainer	62304212
16	Strap bumper (2x)	
17	Strap clip (2x)	
18	Freezer door	62303608
	Hinge freezer door (2x)	
19	Shelf food retainer	62445608
22	Latch bottom*	62400127
23	Bottom latch plate*	
23A	Screw* (3x)	
24	Latch pin lower*	
25	Vegetable bin	62303912
26	Clip shelf small	62362608
27	Cap (2x)	62362208
28	Clip shelf large	62362508
29	Shelf	62303708
30	Fin clip (6x)	623023
31	Shelf	62303808
32	Screw (8x)	
33	Fin	
34	Interior light switch*	62301808
35	Interior light cover*	624002
36	Interior light bulb*	624003
37	Light bracket	

* **Not in all models**



LO 004-EXPLODED

Door & Cabinet Interior N90 (LO 004)

	Single spare part number	Assembly spare part number
1	Screw (3x)	
2	Hinge plate	
3	Hinge pin bottom/washer	
4	Door flat low 525	628157R
	Door flat high 525	625573R
5	Pocket cover	
6	Screw (2x)	
7	Hinge plate	
8	Hinge pin top/washer	
9	Screw (3x)	
10	Screw (2x)	62302407
10A	Screw (2x)	
10B	Strike Plate	
11	Latch	
11A	Storage strap	62467907/-90 (2x)
12	Hinge hole plug	
13	Doorbin	62304908
14	Doorbin	62402408
15	Bottle retainer	62304212
16	Strap bumper (2x)	
17	Strap clip (2x)	
18	Freezer door	62304308
	Hinge freezer door (2x)	
19	Shelf food retainer	62445608
20	Shelf tray insert	62363412
21	Vegetable bin	623617
22	Latch bottom*	62400127
23	Bottom latch plate*	
23A	Screw* (3x)	
24	Latch pin lower*	
25	Flip top cover	623615
26	Clip shelf small	62362608
27	Cap (2x)	62362208
28	Clip shelf large	62362508
29	Shelf	62304708
30	Fin clip (6x)	623023
31	Shelf	62304808
32	Screw (8x)	
33	Fin	
34	Interior light switch*	62301808
35	Interior light cover*	624002
36	Interior light bulb*	624003
37	Light bracket	
*	Not in all models	


Door & Cabinet Interior N112 (LO 004)

Single spare part number

Assembly spare part number

1	Screw (3x)		
2	Hinge plate		
3	Hinge pin bottom/washer		
	Door curved high 525	62509307	
4	Door curved low 525 (as from July 1 st 2005)	62698407	
5	Pocket cover		
6	Screw (2x)		
7	Hinge plate		
8	Hinge pin top/washer		
9	Screw (3x)		
10	Screw (2x)		62302407 62698507 (as from July 1 st 2005)
10A	Screw (2x)		
10B	Strike Plate		
11	Latch Latch (as from July 1 st 2005)		
	Storage strap	62467907 (2x)	
11A	Storage strap (As from July 1 st 2005)	62698607/90 (2x)	
12	Hinge hole plug		
13	Doorbin	62510212	
14	Doorbin	62305312	
15	Bottle retainer		62304212
16	Strap bumper (2x)		
17	Strap clip (2x)		
18	Freezer door		62304308
	Hinge freezer door (2x)	62468008	
19	Shelf food retainer	62445708	
20	Shelf tray insert	62664212	
21	Vegetable bin	623617	
22	Latch bottom*	62400127	
23	Bottom latch plate*		
23A	Screw* (3x)		
24	Latch pin lower*		
25	Top cover	62664112	
26	Clip shelf large	62362508	
27	Cap (2x)	62362208	
28	Clip shelf large	62362508	
29	Shelf	62664308	
30	Fin clip (6x)	623023	
31	Shelf	62305108	
32	Screw (8x)		
33	Fin		
34	Interior light switch*	62301808	
35	Interior light cover*	624002	
36	Interior light bulb*	624003	
37	Light bracket		

* **Not in all models**




Door & Cabinet Interior N98 (LE692)

Single spare part number

Assembly spare part number

1	Screw (4x)		
2	Hinge bottom		
3	Door Mollebusch	629169R	
	Door Vermont Ahorn	629198R	
	Door Elsass Kirschbaum	629199R	
	Door Bodensee Ahorn	629200R	
4	Screw (3x)		
5	Hinge top		
6	Hinge pin top/washer		
7	Latch V3		
8	Screw (2x)		62974490
9	Storage strap	62698607 (Light grey) 62698690 (Dark Grey)	2x
10	Screw (2x)		
11	Strike plate		
12	Doorbin	62974512	
13	Doorbin	62974712	
14	Bottle Retainer	62698912	
15	Rail (2x)		
16	Freezer Door		62304308
	Hinge Freezer Door (2x)	62468008	
17	Screw (8x)		
18	Fin		
19	Interior light switch	624002	
20	Interior light cover	624003	
21	Light bracket		
22	Cap (2x)	62362208	
23	Interior light switch	62301808	
24	Bottom latch plate		
25	Screw (3x)		
26	Screw		
27	Latch bottom	62400127	
28	Ramp up		
29	Clip shelf small	62362608	
30	Fin clip (6x)	623023	
31	Shelf food retainer	62445708	
32	Shelf	63173808	
33	Shelf tray insert	63173912	
34	Vegetable bin	63174012	
35	Latch pin lower		



LO 005-EXPLODED

Door & Cabinet Interior N100 (LO 005)

	Single spare part number	Assembly spare part number
1	Screw (3x)	
2	Hinge plate	
3	Hinge pin bottom/washer	
4	Door flat low 525	628157R
	Door flat high 525	625573R
5	Pocket cover	
6	Screw (2x)	
7	Hinge plate	
8	Hinge pin top/washer	
9	Screw (3x)	
10	Latch	
10a	Screw (2x)	
10b	Storage strap	62467907
10c	Strike plate	
10d	Screw (2x)	
11	Hinge hole plug	
12	Doorbin	62304908
13	Doorbin	62402408
14	Bottle retainer	
15	Strap bumper	62304212
16	Strap clip	
17	Freezer door	
	Hinge freezer door	62468008
18	Shelf food retainer	62445608
19	Shelf tray insert	62363512
20	Vegetable bin	623618
21	Latch bottom*	62400127
22	Bottom latch plate*	
23	Screw* (3x)	
24	Latch pin lower*	
25	Flip top cover	623615
26	Clip shelf large	62362508
27	Cap (2x)	62362208
28	Clip shelf small	62362608
29	Shelf	62305508
30	Fin clip (6x)	623023
31	Shelf	62304708
32	Screw (4x)	
33	Fin	
34	Interior light switch	62301808
35	Interior light cover	624002
36	Interior light bulb	624003
37	Light bracket	
*	Not for all models	

Door & Cabinet Interior N109 (LO 005)


	Single spare part number	Assembly spare part number
1	Screw (3x)	
2	Hinge plate	
3	Hinge pin bottom/washer	
4	Door curved high	62509307
5	Pocket cover	
6	Screw (2x)	
7	Hinge plate	
8	Hinge pin top/washer	
9	Screw (3x)	
10	Latch V1	62302407
10a	Screw (2x)	
10b	Storage strap	
10c	Strike plate	
10d	Screw (2x)	
11	Hinge hole plug	
12	Doorbin	62402508
13	Doorbin	62305308
14	Bottle retainer	62304212
15	Strap bumper (2x)	
16	Strap clip (2x)	
17	Freezer door	62304308
	Hinge freezer door (2x)	
18	Shelf food retainer	62445708
19	Shelf tray insert	62363512
20	Vegetable bin	623618
21	Latch bottom*	62400127
22	Bottom latch plate*	
23	Screw* (3x)	
24	Latch pin lower*	
25	Flip top cover	623615
26	Clip shelf large	62362508
27	Cap (2x)	62362208
28	Clip shelf small	62362608
29	Shelf	62305508
30	Fin clip (6x)	623023
31	Shelf	62304708
32	Screw (8x)	
33	Fin	
34	Interior light switch	62301808
35	Interior light cover	624002
36	Interior light bulb	624003
37	Light bracket	

* **Not for all models**

Door & Cabinet Interior N110 (LO 005)

	Single spare part number	Assembly spare part number
1	Screw (3x)	
2	Hinge plate	
3	Hinge pin bottom/washer	
4	Door tearcurved low 525	62700690
5	Pocket cover	
6	Screw (2x)	
7	Hinge plate	
8	Hinge pin top/washer	
9	Screw (3x)	
10	Latch V1	62700790
10a	Screw (2x)	
10b	Storage strap (2x)	
10c	Strike plate	
10d	Screw (2x)	
11	Hinge hole plug	
12	Doorbin	62402508
13	Doorbin	62305308
14	Bottle retainer	62304212
15	Strap bumper (2x)	
16	Strap clip (2x)	
17	Freezer door	62304308
	Hinge freezer door (2x)	
18	Shelf food retainer	62445608
19	Shelf tray insert	62363512
20	Vegetable bin	623618
21	Latch bottom*	62400127
22	Bottom latch plate*	
23	Screw* (3x)	
24	Latch pin lower*	
25	Flip top cover	623615
26	Clip shelf large	62362508
27	Cap (2x)	62362208
28	Clip shelf small	62362608
29	Shelf	62305508
30	Fin clip (6x)	623023
31	Shelf	62304708
32	Screw (8x)	
33	Fin	
34	Interior light switch	62301808
35	Interior light cover	624002
36	Interior light bulb	624003
37	Light bracket	

* **Not for all models**




LE693

Door & Cabinet Interior N108 (LE693)

Single spare part number

Assembly spare part number


1	Screw (3x)		
2	Panel retainer		
3	Door flat low 525	628157R	
	Door flat high 525	625573R	
4	Screw (2x)		
5	Pocket cover		
6	Latch		62698507 (Doesn't include Hinge hole plug)
7	Hinge hole plug		
8	Storage strap	62467907 (2x)	
9	Doorbin	62304908	
10	Bottle retainer		62304212
11	Strap bumper (2x) Strap clip (2x)		
12	Doorbin	62402408	
13	Freezer door		62304308
14	Hinge freezer door (2x)s	62468008	
15	Shelf food retainer	62445708	
16	Shelf	62305108	
17	Clip shelf large	62362508	
18	Shelf	62664308	
19	Shelf tray insert	62664212	
20	Top cover	62664112	
21	Vegetable bin	623617	
22	Latch pin lower		



LE413-EXPLODED

Door & Cabinet Interior N115 (LE413)

	Single spare part number	Assembly spare part number
1	Screw (4x)	
2	Hinge bottom	
	Door Mollebusch	629169R
	Door Vermont Ahorn	629198R
3	Door Elsass Kirschbaum	629199R
	Door Bodensee Ahorn	629200R
	Door Cappuchino	630601114R
4	Screw (3x)	
5	Hinge top	
6	Hinge pin top/washer	
7	Latch V3	
8	Screw (2x)	62974490
9	Storage strap	62698690/07? (2x)
10	Screw (2x)	
11	Strike plate	
12	Doorbin	62974512
13	Doorbin	62974712
14	Bottle retainer	62698912
15	Rail (2x)	
16	Vegetable bin	623617
17	Top cover	62664112
18	Shelf tray insert	62664212
19	Shelf	62305108
20	Shelf food retainer	62445708
21	Clip shelf large	62362508
22	Screw (8x)	
23	Fin clip (6x)	623023
24	Fin	
25	Light bracket	
26	Interior light bulb	624003
27	Interior light cover	624002
28	Switch	623018
29	Freezer door	
	Hinge Freezer door (2x)	62468008
30	Cap (2x)	62362208
31	Latch pin lower	
32	Latch plate bottom	
33	Ramp up	
34	Latch bottom	629721
35	Screw (1x)	
36	Screw (2x)	



LE289 - EXPLODED


Door and cabinet interior N90 (LE289)

Single spare part number

Assembly spare part number

1	Door flat low 525	62509107	
2	Hinge hole plug		
3	Pocket cover		
4	Screw (4x)		
5	Latch V2		62698507
6	Storage strap V2	62695607	
7	Bottle retainer		
8	Doorbin	62304908	
9	Freezer door		62304308
10	Hinge freezer door (2x)	62468008	
11	Shelf	62304808	
12	Shelf food retainer (2x)	62445608	
13	Clip shelf large	62362508	
14	Shelf	62304708	
15	Clip shelf small	62362608	
16	Shelf tray insert	62363412	
17	Hinge pin (2x)		
18	Vegetable bin	623617	
19	Flip top cover	623615	
20	Doorbin	62402408	
21	Bottle retainer	62304212	
22	Bottom latch pin*		
23	Screw (3x)		
24	Panel retainer		

* **Not for all models**



LE287-EXPLODED


Door and cabinet interior N97 (LE287)

Single spare part number

Assembly spare part number

1	Door curved low 525	62698407	
2	Hinge hole plug		
3	Pocket cover		
4	Screw (4x)		
5	Latch		62698507
6	Storage strap	62695607	
7	Bottle retainer		
8	Doorbin	62402608	
9	Freezer door		62304308
10	Hinge freezer door (2x)	62468008	
11	Shelf	62304808	
12	Shelf food retainer (2x)	62445608	
13	Clip shelf large	62362508	
14	Shelf	62304708	
15	Clip shelf small	62362608	
16	Shelf tray insert	62363412	
17	Hinge pin (2x)		
18	Vegetable bin	623617	
19	Flip top cover	623615	
20	Doorbin	62305308	
21	Bottle retainer	62304212	
22	Bottom latch pin*		
23	Screw (3x)		
24	Panel retainer		

* **Not for all models**




Door and cabinet interior N100 (LE293)

Single spare part number

Assembly spare part number

1	Door flat low 525	628157R	
2	Hinge hole plug		
3	Pocket cover		
4	Screw (4x)		
5	Latch		62698507
6	Storage strap	62695607	
7	Bottle retainer		
8	Doorbin	62304908	
9	Freezer door		62304308
10	Hinge freezer door (2x)	62468008	
11	Shelf	62304708	
12	Shelf food retainer (2x)	62445608	
13	Clip shelf small	62362608	
14	Shelf	62304708	
15	Clip shelf large	62362508	
16	Shelf tray insert	62363512	
17	Hinge pin (2x)		
18	Vegetable bin	623618	
19	Flip top cover	623615	
20	Doorbin	62402408	
21	Bottle retainer	62304212	
22	Bottom latch pin*		
23	Screw (3x)		
24	Panel retainer		


* **Not for all models**



Door and cabinet interior N104-109 (LE292)

	Single spare part number	Assembly spare part number
1	Door curved low 525	62698407
2	Hinge hole plug	
3	Pocket cover	
4	Screw (4x)	
5	Latch	62698507
6	Storage strap	
7	Bottle retainer	
8	Doorbin	62402508
9	Freezer door	62304308
10	Hinge freezer door (2x)	
11	Shelf	62304708
12	Shelf food retainer (2x)	62445708
13	Clip shelf small	62362608
14	Shelf	62305508
15	Clip shelf large	62362508
16	Shelf tray insert	62363512
17	Hinge pin (2x)	
18	Vegetable bin	623618
19	Flip top cover	623615
20	Doorbin	62305312
21	Bottle retainer	62304212
22	Bottom latch pin*	
23	Screw (3x)	
24	Panel retainer	

* **Not for all models**



LE290 - EXPLODED

Door and cabinet interior N112 (LE290)

Single spare part number


Assembly spare part number

1	Door curved low 525	62698407	
2	Hinge hole plug		
3	Pocket cover		
4	Screw (4x)		
5	Latch		62698507
6	Storage strap	62695607	
7	Bottle retainer		
8	Doorbin	62510212	
9	Freezer door		62304308
10	Hinge freezer door (2x)	62468008	
11	Shelf	62305108	
12	Shelf food retainer (2x)	62445708	
13	Clip shelf large	62362508	
14	Shelf	62664308	
15	Shelf tray insert	62664212	
16	Top cover***	62664112	
17	Vegetable bin***	623617	
18	Doorbin	62305312	
19	Bottle retainer	62304212	
20	Bottom latch pin*		
21	Screw (3x)		
22	Panel retainer		

* **Not for all models**

*** **Model change as from July 2005:**


Before this date these parts cannot be replaced separately, but both must be replaced.



LE298-EXPLODED

Door and cabinet interior N145 (LE298)

		Single spare part number	Assembly spare part number
1	Door flat double cab.	62509407	
2	Bottle retainer		
3	Hinge hole plug (2x)		
4	Storage strap V2 (2x)	62698607	62698507
5	Latch V2 (2x)		
6	Pocket cover (2x)		
7	Screw (8x)		
8	Door flat double fr.	62509507	
9	Screw (6x)		
10	Panel retainer		
11	Doorbin (2x)	624023-08/-12	
12	Doorbin	623040-08/-12	
13	Shelf	62363308	
14	Shelf food retainer (3x)	62445608	
15	Shelf	62304408	
16	Clip shelf small	62362608	
17	Shelf	62304508	
18	Clip shelf large (2x)	62362508	
19	Shelf tray insert	62363612	
20	Hinge pin		
21	Vegetable bin	623619	
22	Flip top cover	623616	
23	Bottom latch pin*		
24	Panel retainer		
*	Not for all models		



LE291-EXPLODED


Door and cabinet interior N150 (LE291)

Single spare part number

Assembly spare part number

1	Door curved double cab.	62698207	
2	Hinge hole plug (2x)		
3	Storage strap V2 (2x)	62698607	
4	Latch V2 (2x)		62698507
5	Pocket cover (2x)		
6	Screw (8x)		
7	Door curved double fr.	62698307	
8	Screw (3x)		
9	Panel retainer		
10	Doorbin (2x)	62697612	
11	Shelf	62363308	
12	Shelf food retainer	62445708	
13	Shelf	62697808	
14	Clip shelf large (3x)	62362508	
15	Shelf (2x)	62697908	
16	Shelf tray insert	62698112	
17	Vegetable bin	62698012	
18	Doorbin (2x)	6269712	
19	Bottle retainer	62698912	
20	Bottom latch pin*		
21	Panel retainer		
22	Screw (3x)		

* **Not for all models**




Door and cabinet interior N175 (LE694)

Single spare part number

Assembly spare part number

1	Bottom latch pin		
2	Screw (3x)		
3	Panel retainer		
4	Door curved double cab.	62698207	
5	Hinge hole plug (2x)		
6	Latch V2 (2x)		62698507
7	Storage Strap (2x)	62698607	
8	Pocket cover (2x)		
9	Screw (8x)		
10	Door curved double fr.	62698307	
11	Panel retainer		
12	Screw (3x)		
13	Doorbin (2x)	62697612	
14	Doorbin (2x)	62697712	
15	Bottle retainer	62698912	
16	Shelf	63174108	
17	Shelf food retainer	62445708	
18	Shelf	63174208	
19	Shelf	63174308	
20	Clip shelf large (3x)	62362508	
21	Shelf	63174408	
22	Shelf tray insert	62698112	
23	Vegetable bin	63174508	




LE423-EXPLODED

Door and cabinet interior N180 (LE423)

Single spare part number

Assembly spare part number


	Single spare part number	Assembly spare part number
1	Door curved XL IC 525	62972407
2	Hinge hole plug	
3	Control panel	
4	Screw (2x)	
5	Pocket cover	
6	Screw (2x)	62698507
7	Latch V2	
8	Screw (2x)	
9	Storage strap V2	62698607
10	Rail retainer	
11	Door rail (3x)	
12	Doorbin	629719
13	Shelf bottle	629725
14	Clip shelf large (5x)	62362508
15	Freezer door	62304308
16	Hinge freezer door (2x)	
17	Shelf (2x)	629726
18	Shelf	629727
19	Shelf food retainer (3x)	62445608
20	Shelf tray insert	62698112
21	Vegetable bin	62698012
22	Bottle retainer	62698912
23	Bottom latch pin	
24	Screw (2x)	
25	Panel retainer	



LO 008-EXPLODED

Cooling Unit and Burner Box N80, 90, 97, 98, 100, 104, 108, 109, 110, 112, 115 (LO008)


	Single spare part number	Assembly spare part number
1	Cooling unit	
	Flue exhaust long	624480
2	Flue exhaust short	<u>N100, 104 and 110 use:</u> 627008
3	Flame diffuser	
4	Burner	
4a	Orifice	623019
4b	Screw	
5	Thermocouple V2	
5a	Retainer thermocouple	625681
5b	Screw (2x)	
6	Burner box base	
	<i><u>Piezo ignition</u></i>	
7	Spark electrode	
7a	Screw	627004
7b	Bushing	
	<i><u>Electrical ignition</u></i>	
7	Spark electrode	
7a	Screw	623021 (No screw?)
7b	Bushing	
8	Screw (2x)	
9	Speed nut	624027
10	Screw insulation cover	624026
11	Burner box cover	
12	Screw	
13	Drip cup	
	<i><u>Electrical models</u></i>	
14	Electronic ignition	623022
14a	Screw (2x)	
15	Heater AC	623064 628450 **
16	Heater DC	623065
**	As from July 1st 2005	



LE238-EXPLODED

Cabinet and cooling unit N90, 97, 112 (LE238)


	Single spare part number	Assembly spare part number
1	Cabinet	
2	Foot (2x)	
3	Screw* (9x)	
4	Bottom latch plate*	
5	Latch bottom*	62400127
6	Hinge plate	
7	Hinge pin bottom/washer	
8	Thermistor	623077
9	Fin clip	623059
10	Screw (8x)	
11	Fin	
12	Cap freezer bolt (12x)	62447908
13	Screw (2x)	
14	Strike plate	
15	Hinge plate	
16	Hinge pin top/washer	
17	Interior light switch	623061
18	Strap (2x)	
19	Heat diffuser	
20	Screw (2x)	
21	Cooling unit	
22	Heater AC	626994
23	Heater DC	626995
24	Light bracket	
25	Interior light bulb	624003
26	Interior light cover	624002
27	Cap (2x)	62362208
*	Not for all models	



LE226 - EXPLODED

Cabinet and cooling unit N100, 104 (LE226)


	Single spare part number	Assembly spare part number
1	Cabinet	
2	Foot (2x)	
3	Screw* (9x)	
4	Bottom latch plate*	
5	Latch bottom*	62400127
6	Hinge plate	
7	Hinge pin bottom/washer	
8	Thermistor	623077
9	Fin clip	623059
10	Screw (8x)	
11	Fin	
12	Cap freezer bolt (12x)	62447908
13	Screw (2x)	
14	Strike plate	
15	Hinge plate	
16	Hinge pin top/washer	
17	Interior light switch	623061
18	Strap (2x)	
19	Heat diffuser	
20	Screw (2x)	
21	Cooling unit	
22	Heater AC	626994
23	Heater DC	626995
24	Light bracket	
25	Interior light bulb	624003
26	Interior light cover	624002
27	Cap (2x)	62362208
*	Not for all models	



LE259 - EXPLODED

Cabinet and cooling unit N109 (LE259)

	Single spare part number	Assembly spare part number
1	Cabinet	
2	Foot (2x)	
3	Screw* (9x)	
4	Bottom latch plate*	
5	Latch bottom*	62400127
6	Hinge plate	
7	Hinge pin bottom/washer	
8	Thermistor	623077
9	Fin clip	623059
10	Screw (8x)	
11	Fin	
12	Cap freezer bolt (12x)	62447908
13	Screw (2x)	
14	Strike plate	
15	Hinge plate	
16	Hinge pin top/washer	
17	Interior light switch	623061
18	Strap (2x)	
19	Heat diffuser	
20	Screw (2x)	
21	Cooling unit	
22	Heater AC	626994
23	Heater DC	626995
24	Light bracket	
25	Interior light bulb	624003
26	Interior light cover	624002
27	Cap (2x)	62362208
*	Not for all models	




Cabinet and cooling unit N145, 150 (LE232)

Single spare part number

Assembly spare part number

1	Cabinet	
2	Foot (4x)	
3	Screw* (9x)	
4	Bottom latch plate*	
5	Latch bottom*	62400127
6	Hinge plate	
7	Hinge pin bottom/washer	
8	Fin clip	623059
9	Thermistor	623077
10	Screw (4x)	
11	Fin	
	Drain plate	631190
12	Screw (4x)	
13	Strike plate (2x)	
14	Screw (4x)	
15	Hinge center pin	
16	Hinge center bracket	
17	Cap freezer bolt (12x)	62447908
18	Hinge plate	
19	Hinge pin top/washer	
20	Cap (2x)	62362208
21	Interior light switch	623061
22	Light bracket	
23	Interior light bulb	624003
24	Interior light cover	624002
25	Heat diffuser	
26	Screw (2x)	
27	Cooling unit	
28	Heater AC	626998
	Heater DC (between May '05 - June '06)	626993
29	Heater DC (between June '06- March '08)	631751
	Heater DC (as from March '08)	631752
30	Screw (2x)	

* **Not for all models**



LE707


Cabinet and cooling unit N175 (LE707)

Single spare part number

Assembly spare part number

1	Cabinet		
2	Foot (4x)		
3	Screw* (9x)		
4	Bottom latch plate*		
5	Latch bottom*	62400127	
6	Hinge plate		
7	Hinge pin bottom/washer		
8	Fin clip	623059	
9	Thermistor	623077	
10	Screw (4x)		
11	Fin Drain plate		631190
12	Screw (4x)		
13	Strike plate (2x)		
14	Screw (4x)		
15	Hinge center pin		
16	Hinge center bracket		
17	Cap freezer bolt (12x)	62447908	
18	Hinge plate		
19	Hinge pin top/washer		
20	Cap (2x)	62362208	
21	Interior light switch	623061	
22	Light bracket		
23	Interior light bulb	624003	
24	Interior light cover	624002	
25	Heat diffuser		
26	Screw (2x)		
27	Cooling unit		
28	Heater AC	626998	
	Heater DC (between May '05 - June '06)	626993	
29	Heater DC (between June '06- March '08)	631751	
	Heater DC (as from March '08)	631752	
30	Screw (2x)		

* **Not for all models**




LE 424-EXPLODED

Cabinet and cooling unit N180 (LE424)

Single spare part number

Assembly spare part number

1	Cabinet		
2	Foot (2x)		
3	Screw (2x)		
4	Interior light switch	629722	
5	Latch plate bottom		
6	Screw		629721
7	Latch bottom		
8	Ramp up		
9	Hinge cap (2x)		
10	Screw (8x)		
11	Hinge plate bottom		
12	Washer		
13	Cable flexible	629723	
14	Cap (2x)	62362208	
15	Light bracket		
16	Interior light bulb	624003	
17	Interior light cover	624002	
18	Screw(4x)		
19	Fin clip	623059	
20	Fin Drain plate		631190
21	Thermistor	623077	
22	Cap freezer bolt (12x)	62447908	
23	Screw (4x)		
24	Strike plate (2x)		
25	Hinge plate		
26	Hinge pin top/washer		
27	Screws (3x)		
28	Cooling unit		
29	Heat diffuser		
30	Screw (2x)		
31	Heater AC	626992	
	Heater DC (produced between April '06 - December 4 th '07)	626993	
32	Heater DC (produced between December 5 th '07 - March 16 th '08)	631751	
	Heater DC (produced as from March 17 th '08)	631752	




Power board and gas assembly N90, -97, -100, -104, -109, -112 (LE439)

	Single spare part number	Assembly spare part number
1	Screw (2x)	
	Gas valve automatic V3	631249 **
2 *	Gas valve automatic V4 (N100 & -104)	631248 **
	Gas valve automatic V5	630440
3	Gas inlet tube	
4	Screw (6x)	
5	Strain relief cover	
6	Earth connection	
7	Screw (2x)	
8	Power board cover	
9	<i>Smart Energy Selection Models</i> Power board A V3	634420 (includes housing)
	<i>Electric Energy Selection Models</i> Power board E V3	634421 (includes housing)
10	Power board base	
11	Screw (3x)	
12	Drip cup	
13	Spark electrode	636988
14	Screw (2x)	
15	Bushing	
16	Gastube	
17	Mounting bracket gas valve	
18	Burner	623019
19	Burner box base	
20	Burner box cover	
21	Washer	
22	Screw (3x)	

V3 and V4 gas valves are to be replaced by a V5 version. Which version is installed on the fridge can be checked by the number on the part itself. V3 & V4 = 626967, V5 = 628453.
 * When a V3 or V4 is installed, order the assembly spare part to convert to a V5.

** These assembly spare parts include instructions, a V5 gas valve and a compatible gas inlet tube.




LE-439 EXPLODED

Power board and gas assembly N145, N150, N175, N180 (LE439)

	Single spare part number	Assembly spare part number
1	Screw (2x)	
2 *	Gas valve automatic V4	631248 **
	Gas valve automatic V5	630440
3	Gas inlet tube	
4	Screw (6x)	
5	Strain relief cover	
6	Earth connection	
7	Screw (2x)	
8	Power board cover	
9	<i>Smart Energy Selection Models</i> Power board A V3	634422 (includes housing)
	<i>Electric Energy Selection Models</i> Power board E V3	634423 (includes housing)
10	Power board base	
11	Screw (3x)	
12	Drip cup	
13	Spark electrode	626987
14	Screw (2x)	
15	Bushing	
16	Gastube	
17	Mounting bracket gas valve	
18	Burner	623058
19	Burner box base	
20	Burner box cover	
21	Washer	
22	Screw (3x)	

* V4 gas valves are to be replaced by a V5 version. Which version is installed on the fridge can be checked by the number on the part itself. V4 = 626967, V5 = 628453.
When a V4 is installed, order the assembly spare part to convert to a V5.

** This assembly spare part includes instructions, a V5 gas valve and a compatible gas inlet tube.



LO 009-EXPLODED

Seals, vents and exhausts for all models

		Single spare part number	Assembly spare part number
1	Flue exhaust short	627008	
	Flue exhaust long	624480	
1a	Clamp		
2	Combustion flap 486	624021	
	Combustion flap 525	624020	
3	Vent cap	625096	
4	Vent frame		
5	Vent lock clip	628449	
5a	Vent screen		
5b	Vent outer		
6	Vent cover small	624455	
	Vent cover large	631150	
7	Cabinet side seal 605		
	Cabinet side seal 821		
	Cabinet side seal 1245		
	Vent small complete		
	Vent large complete		

Colourindex

Note: Some spare part no.s contain a colour code. These are shown as the last 2 digits following a hyphen

		Code
06	Grey	RAL 7015
07	Light grey	RAL 7042
08	White	MP 1013 MP FR85 R7
12	Blue	RAL 5012
13	Chrome	Not available
14	Nickel	Not available
15	Light Grey	Not available
22	White cream	Not available
25	Grey	7000
27	Black	4500
30	Mocca	S 2005-YUOR
57	Cream white	RAL 9001
80	White	BASF 31573
84	White grey	Fiat Bianca 210
90	Antracite grey	RAL 7016

Explanation codes Thetford refrigerators

F.i. E128A6987

E = standard for all refrigerators

128 = day of the year

A = code year of production (see underneath for all years)

6987 = Thetford code (not relevant)

A = 2002

C = 2003

D = 2004

E = 2005

F = 2006

G = 2007

H = 2008

K = 2009

L = 2010

Overview frameless fridge doors for replacement

629676-107(R)	Door final N97/N104/N112 Anthracite (Smoke PF)
629678-107(R)	Door final cabinet N150/N175 Anthracite (Smoke PF)
629680-107(R)	Door final freezer N150/N175 Anthracite (Smoke PF)
629676-110(R)	Door final N97/N104/N112 Titan brushed
629678-110(R)	Door final cabinet N150/N175 Titan brushed
629680-110(R)	Door final freezer N150/N175 Titan brushed